Hydrogen Energy Development Fund
Operated & managed by Secure Supplies Investments limited
fueling healthy communities

SCALING Nano Bubble Water Fuel Cells Hydrogen Hot Rod, Voltrolysis Parts & the Donatelli Cycle Ecosystem

Stanley Meyer WFC Scaling Analysis: 6-Cell vs 10-Cell Configuration Scale up

The mathematical framework for scaling from a 10-cell to 6-cell Water Fuel Cell (WFC) configuration.

Fundamental Scaling Relationships

1. Electrical Parameter Scaling (Parallel Configuration)

For a typical Stanley Meyer WFC with tubes connected in parallel:
Capacitance Scaling:

- 10-cell total capacitance: $C_{10} = 10 \times C_unit$
- 6-cell total capacitance: $C_6 = 6 \times C_unit$
- Scaling ratio: 0.600 (6-cell has 60% of original capacitance)

Resistance Scaling:

- 10-cell total resistance: $R_{10} = R_unit \div 10$
- 6-cell total resistance: $R_6 = R_unit \div 6$
- Scaling ratio: 1.667 (6-cell has 67% higher resistance)

Inductance Scaling:

- 10-cell total inductance: $L_{10} = L_unit \div 10$
- 6-cell total inductance: $L_6 = L_unit \div 6$
- Scaling ratio: 1.667 (6-cell has 67% higher inductance)

Copyright 2025 © Daniel Donatelli Secure Supplies Group All Rights Reserved

2. Resonance Frequency Analysis

The resonance frequency formula $f = 1/(2\pi\sqrt{LC})$ shows that for parallel-connected tubes, the resonance frequency remains constant when scaling proportionally, since both L and C change by the same factor[34].

However, the quality factor (Q) and impedance characteristics change significantly:

- Impedance at resonance increases by factor of 1.667
- This affects the VIC coupling and requires adjustment

3. VIC (Voltage Intensifier Circuit) Adjustments

Based on transformer scaling principles documented in Meyer's patents[56]:

Voltage Scaling: Reduce by factor of 0.775

Current Scaling: Increase by factor of 1.291

Power Scaling: Remains approximately constant

4. Component Adjustment Requirements

To maintain proper resonance with 6 cells instead of 10:

Option A - Inductance Adjustment:

- Decrease external inductance by factor of 0.600
- This compensates for the higher cell inductance

Option B - Frequency Adjustment:

- Keep same inductance values
- Accept the impedance change and adjust VIC turns ratio accordingly

Option C - Capacitance Compensation:

- Add external capacitance to restore original total capacitance
- Increase external capacitance by factor of 1.667

Copyright 2025 © Daniel Donatelli Secure Supplies Group All Rights Reserved

Practical Implementation Recommendations

1. Gas Production Expectations

Theoretical gas output should scale linearly with active surface area:

- Expected output: 60% of original 10-cell configuration
- This assumes equivalent power input and efficiency maintenance

2. Electrical System Modifications

VIC Secondary Voltage: Increase by 29% to compensate for higher cell impedance
Drive Current: Expect 29% higher current draw from power supply
Resonance Tuning: The cell will have 67% higher impedance, requiring either:

- Lower driving frequency, or
- Modified external L/C components, or
- Adjusted VIC turns ratio

3. Critical Design Considerations

Impedance Matching: The higher impedance of the 6-cell configuration will affect power transfer efficiency. Proper impedance matching through VIC adjustment is crucial

Temperature Effects: Fewer cells mean higher current density per cell, potentially affecting operating temperature and requiring enhanced cooling
Resonance Stability: The higher Q-factor may make the system more sensitive to frequency drift and component tolerances

Mathematical Summary

Copyright 2025 © Daniel Donatelli Secure Supplies Group All Rights Reserved

Parameter	6-Cell/10-Cell Ratio	Adjustment Required
Total Capacitance	0.600	Add external C or adjust frequency
Total Resistance	1.667	VIC impedance matching
Total Inductance	1.667	Reduce external L by 40%
Resonance Frequency	1.000	Maintain with component adjustment
Cell Impedance	1.667	VIC secondary voltage +29%
Expected Gas Output	0.600	Inherent reduction
Drive Current	1.291	Power supply capacity check

Specific Scaling Formulas

The general scaling principles from the forum discussions align with these electromagnetic theory-based calculations.

The key insight is that proportional scaling maintains resonance frequency but changes impedance characteristics, requiring careful VIC adjustment for optimal performance.

Recommended to start with Option A
(reducing external inductance)
as it provides the most straightforward path to maintaining system resonance while accommodating the 6-cell configuration's changed electrical characteristics.

Copyright 2025 © Daniel Donatelli Secure Supplies Group All Rights Reserved

Hydrogen Energy Development Fund
Operated & managed by Secure Supplies Investments limited
fueling healthy communities

Stanley Meyer WFC Scaling Calculator & Builder's Guide

Based on comprehensive analysis of Stanley Meyer's Water Fuel Cell technology and electrical scaling principles, this guide provides precise calculations for scaling WFC configurations from 12 to 1200 cells in parallel configuration.

Fundamental Scaling Relationships

The scaling calculations are based on well-established electrical engineering principles for parallel circuit configurations. When cells are connected in parallel, the following relationships apply

Capacitance Scaling: Total capacitance increases linearly with cell count

Ctotal=n × Cunit

$C_{total} = n \times C_{unit}$

Resistance Scaling: Total resistance decreases inversely with cell count

Rtotal=Runitn

$R_{total} = n R_{unit}$

Inductance Scaling: Total inductance decreases inversely with cell count

Ltotal=Lunitn

$L_{total} = n$

L_{unit}

Current Scaling: Total current increases linearly with cell count (at constant voltage)

Itotal=n×Iunit

$I_{Total} = n \times I_{unit}$

Copyright 2025 © Daniel Donatelli Secure Supplies Group All Rights Reserved



Stanley Meyer WFC electrical parameter scaling showing how capacitance, resistance, impedance, current, and gas output ratios change with cell count (base: 10 cells)

Copyright 2025 © Daniel Donatelli Secure Supplies Group All Rights Reserved

Complete Scaling Parameters Table

Cell Count	Capacitance Ratio	Resistance Ratio	Inductance Ratio	Impedance Ratio	Current Ratio	Gas Output Ratio	VIC Voltage Ratio	VIC Current Ratio
12	1.200	0.833	0.833	0.833	1.2	1.2	0.913	1.2
14	1.400	0.714	0.714	0.714	1.4	1.4	0.845	1.4
16	1.600	0.625	0.625	0.625	1.6	1.6	0.791	1.6
18	1.800	0.556	0.556	0.556	1.8	1.8	0.745	1.8
20	2.000	0.500	0.500	0.500	2.0	2.0	0.707	2.0
22	2.200	0.455	0.455	0.455	2.2	2.2	0.674	2.2
24	2.400	0.417	0.417	0.417	2.4	2.4	0.645	2.4
26	2.600	0.385	0.385	0.385	2.6	2.6	0.620	2.6
28	2.800	0.357	0.357	0.357	2.8	2.8	0.598	2.8

Copyright 2025 © Daniel Donatelli Secure Supplies Group All Rights Reserved

30	3.000	0.333	0.333	0.333	3.0	3.0	0.577	3.0
40	4.000	0.250	0.250	0.250	4.0	4.0	0.500	4.0
60	6.000	0.167	0.167	0.167	6.0	6.0	0.408	6.0
80	8.000	0.125	0.125	0.125	8.0	8.0	0.354	8.0
100	10.000	0.100	0.100	0.100	10.0	10.0	0.316	10.0
120	12.000	0.083	0.083	0.083	12.0	12.0	0.289	12.0
160	16.000	0.063	0.063	0.063	16.0	16.0	0.250	16.0
200	20.000	0.050	0.050	0.050	20.0	20.0	0.224	20.0
320	32.000	0.031	0.031	0.031	32.0	32.0	0.177	32.0
400	40.000	0.025	0.025	0.025	40.0	40.0	0.158	40.0
600	60.000	0.017	0.017	0.017	60.0	60.0	0.129	60.0

Copyright 2025 © Daniel Donatelli Secure Supplies Group All Rights Reserved

800	80.000	0.013	0.013	0.013	80.0	80.0	0.112	80.0
1200	120.000	0.008	0.008	0.008	120.0	120.0	0.091	120.0

All ratios are relative to 10-cell base configuration

Component Adjustment Requirements

Resonance Maintenance Options

Option A - External Inductance Adjustment:

- Reduce external inductance by the inductance ratio factor
- For 20 cells: Reduce external L by 50%
- For 100 cells: Reduce external L by 90%

Option B - External Capacitance Adjustment:

- Increase external capacitance by the capacitance ratio factor
- For 20 cells: Increase external C by 100%
- For 100 cells: Increase external C by 900%

Option C - VIC Transformer Adjustment:

- Adjust VIC secondary turns ratio by the VIC voltage ratio
- For 20 cells: Increase turns ratio by 41.4%
- For 100 cells: Increase turns ratio by 216%

Copyright 2025 © Daniel Donatelli Secure Supplies Group All Rights Reserved

Critical Component Adjustments Table

Cell Count	External L Reduction %	External C Increase %	VIC Turns Change %	Current Draw Change %	Power Supply Increase %
12	16.7%	20.0%	9.5%	20.0%	20.0%
20	50.0%	100.0%	41.4%	100.0%	100.0%
30	66.7%	200.0%	73.2%	200.0%	200.0%
60	83.3%	500.0%	144.9%	500.0%	500.0%
100	90.0%	900.0%	216.2%	900.0%	900.0%
200	95.0%	1900.0%	347.2%	1900.0%	1900.0%
400	97.5%	3900.0%	532.5%	3900.0%	3900.0%
1200	99.2%	11900.0%	1000.0%	11900.0%	11900.0%

Copyright 2025 © Daniel Donatelli Secure Supplies Group All Rights Reserved

Builder's Practical Guide

Complexity & Skill Level Classifications

Beginner Level (12-20 cells):

- Air cooling sufficient
- Standard automotive power supply (12-24V)
- Basic electrical skills required
- Build time: 2-3 days
- Estimated current draw: 6-10A

Intermediate Level (22-60 cells):

- Enhanced air cooling needed
- Standard automotive power supply (12-24V)
- Advanced electrical knowledge required
- Build time: 3-4 days
- Estimated current draw: 11-30A

Advanced Level (80-200 cells):

- Water cooling recommended
- High-current switching power supply (24-48V)
- Professional electrical expertise required
- Build time: 4-6 days
- Estimated current draw: 40-100A

Expert Level (320-1200 cells):

- Active water cooling required
- Industrial switching power supply (48-72V)
- Engineering-level expertise required
- Build time: 8-24 days
- Estimated current draw: 160-600A

Copyright 2025 © Daniel Donatelli Secure Supplies Group All Rights Reserved

Power Supply Requirements

The power supply must handle the scaled current requirements while maintaining voltage stability. For parallel cell configurations, current scales linearly while voltage remains constant[12].

Current Draw Estimation:

- Base: 10 cells @ 5A = 0.5A per cell
- Scaled: N cells @ (N × 0.5A)
- Safety margin: Add 25% for startup surge

Voltage Requirements:

- Maintain constant voltage across all parallel branches
- Higher cell counts require better voltage regulation
- Ripple voltage must be <1% for stable resonance

Safety Considerations

Standard Safety (12-20 cells):

- Basic electrical safety practices
- Standard automotive fusing
- Proper grounding essential

Enhanced Safety (22-100 cells):

- Arc flash protection required
- Current limiting circuits recommended
- Thermal monitoring essential

Industrial Safety (120-1200 cells):

- Professional electrical safety protocols
- Multiple safety interlocks required
- Automated shutdown systems mandatory
- Proper electrical room/enclosure required

Copyright 2025 © Daniel Donatelli Secure Supplies Group All Rights Reserved

Resonance Frequency Considerations

The resonance frequency relationship is given by

$$f=12\pi LC$$

$$f=2\pi\ LC1$$

Since both L and C scale proportionally in parallel configurations, the resonance frequency theoretically remains constant. However, practical considerations include:

Quality Factor (Q) Changes:

- Q increases with cell count due to lower total resistance
- Higher Q means sharper resonance peak
- Requires more precise frequency control

Temperature Stability:

- More cells generate more heat
- Capacitance changes with temperature
- Cooling system becomes critical for frequency stability

Practical Implementation Guidelines

Copyright 2025 © Daniel Donatelli Secure Supplies Group All Rights Reserved

Step-by-Step Scaling Process

1. Calculate Target Parameters:
    - Determine required gas output
    - Select appropriate cell count from table
    - Identify complexity level and skill requirements
2. Component Selection:
    - Choose adjustment option (A, B, or C)
    - Calculate new component values using scaling ratios
    - Source appropriate power supply capacity
3. Resonance Tuning:
    - Start with calculated values
    - Fine-tune using adjustable components
    - Monitor temperature and frequency stability
4. Performance Verification:
    - Measure actual current draw vs. calculated
    - Verify gas output scaling
    - Check resonance frequency stability

Common Scaling Mistakes to Avoid

Electrical Errors:

- Using series scaling formulas for parallel configurations
- Forgetting to account for VIC impedance matching
- Undersizing power supply capacity

Mechanical Errors:

- Inadequate cooling for high cell counts
- Poor electrical connections causing hot spots
- Insufficient mechanical support for large arrays

Safety Errors:

- Ignoring arc flash potential in high-current systems
- Inadequate fusing and protection
- Poor grounding practices

Advanced Scaling Considerations

Copyright 2025 © Daniel Donatelli Secure Supplies Group All Rights Reserved

Non-Linear Effects

While the basic scaling relationships are linear, several non-linear effects become significant at high cell counts:

Skin Effect: At high frequencies, current concentrates near conductor surfaces, effectively increasing resistance

Proximity Effect: Magnetic fields from adjacent cells can affect inductance values

Thermal Runaway: Uneven heating can create positive feedback loops in large arrays

Optimization Strategies

Modular Approach:

For very high cell counts (>200), consider multiple smaller modules rather than one large array

Active Balancing:

Implement current monitoring and balancing circuits for large arrays

Thermal Management: Use thermal modeling to optimize cooling system design

This comprehensive scaling guide provides the mathematical foundation and practical guidance needed for successful Stanley Meyer WFC scaling across the complete range from 12 to 1200 cells, enabling builders to make informed decisions based on their skill level, available resources, and performance requirements.

Here's a smart builder's guide for scaling Stanley Meyer-style Water Fuel Cells (WFC) when the tubes are wired in **series—specifically** for 6-cell and 10-cell configurations.

Copyright 2025 © Daniel Donatelli Secure Supplies Group All Rights Reserved

Hydrogen Energy Development Fund
Operated & managed by Secure Supplies Investments limited
fueling healthy communities

Stanley Meyer WFC Series Wiring Scaling Guide (6 vs. 10 Cells)

Key Electrical Principles for Series Wiring

When you wire WFC tubes in series:

- Total Voltage = Sum of voltages across each cell (increases with more cells)
- Total Capacitance = Decreases as more cells are added (like resistors in parallel)
- Total Resistance = Increases with more cells (sum of all cell resistances)
- Total Inductance = Increases with more cells (sum of all cell inductances)
- Current = Same through all cells

Formulas

- Total Capacitance:
- Ctotal=CunitN
- $C_{total}=NC_{unit}$
- Total Resistance:
- Rtotal=N×Runit
- $R_{total}=N\times R_{unit}$
- Total Inductance:
  Ltotal=N×Lunit
- $L_{total}=N\times L_{unit}$
- Total Voltage Required:
- Vtotal=N×Vunit
- $V_{total}=N\times V_{unit}$
- Resonant Frequency:
- f=12πLtotalCtotal
- $f=2\pi L_{total}C_{total}1$

Series Wiring Comparison Table

Copyright 2025 © Daniel Donatelli Secure Supplies Group All Rights Reserved

Parameter	6 Cells (Series)	10 Cells (Series)	Scaling Factor (10/6)
Capacitance	Cunit/6$C_{unit}/6$	Cunit/10$C_{unit}/10$	0.6
Resistance	6×Runit6$\times R_{unit}$	10×Runit10$\times R_{unit}$	1.67
Inductance	6×Lunit6$\times L_{unit}$	10×Lunit10$\times L_{unit}$	1.67
Voltage Needed	6×Vunit6$\times V_{unit}$	10×Vunit10$\times V_{unit}$	1.67
Current	Same as 1 cell	Same as 1 cell	1
Resonant Freq.	f6=12π6Lunit · (Cunit/6)=12πLunitCunit $f_6=2\pi 6L_{unit}\cdot(C_{unit}/6)1$ $=2\pi L_{unit}C_{unit}1$	f10=12π10Lunit · (Cunit/10)=12πLunitCunit $f_{10}=2\pi 10L_{unit}\cdot(C_{unit}/10)1$ $=2\pi L_{unit}C_{unit}1$	1

Notice:

Copyright 2025 © Daniel Donatelli Secure Supplies Group All Rights Reserved

- Resonant frequency stays the same (since
- L
- L and
- $1/\mathrm{C}$
- $1/C$ scale equally).
- Voltage requirement increases linearly with the number of series cells.
- Capacitance drops as you add more cells in series, making the circuit more sensitive to noise and voltage spikes.

Practical Builder Tips

1. Power Supply

- You must supply a higher voltage for more series cells.
- For 6 cells: 6× cell voltage; for 10 cells: 10× cell voltage.

2. Component Selection

- Inductor: Increase inductance in proportion to the number of cells.
- Capacitor: Total capacitance drops, so resonance is more sensitive. Use high-quality, low-ESR capacitors if needed for tuning.
- Wiring: Current is the same as a single cell, but insulation must handle higher voltage.

3. Safety

- Higher series voltages = higher shock risk. Use proper insulation and safety protocols.
- Carefully check for arcing and insulation breakdown at high voltages.

4. Performance

- Gas output per cell is the same, but total voltage divides across all cells.
- Series wiring is less common for high-output HHO systems, but is essential for Meyer's "resonant charging" approach.

Example Calculation

Copyright 2025 © Daniel Donatelli Secure Supplies Group All Rights Reserved

Assume each cell:

- Capacitance: 1 nF
- Resistance: 10 Ω
- Inductance: 1 mH
- Voltage: 12 V

6 Cells in Series:

- Capacitance:
- 1 nF/6=0.167 nF
- 1nF/6=0.167nF
- Resistance:
- 6×10 Ω=60 Ω
- 6×10Ω=60Ω
- Inductance:
- 6×1 mH=6 mH
- 6×1mH=6mH
- Voltage Needed:
- 6×12 V=72 V
- 6×12V=72V

10 Cells in Series:

- Capacitance:
- 1 nF/10=0.1 nF
- 1nF/10=0.1nF
- Resistance:
- 10×10 Ω=100 Ω
- 10×10Ω=100Ω
- Inductance:
- 10×1 mH=10 mH
- 10×1mH=10mH
- Voltage Needed:
- 10×12 V=120 V
- 10×12V=120V

Copyright 2025 © Daniel Donatelli Secure Supplies Group All Rights Reserved

Summary Table

Cells	Total Capacitance	Total Resistance	Total Inductance	Voltage Needed	Resonant Freq. (if L_unit & C_unit constant)
6	0.167 nF	60 Ω	6 mH	72 V	Same as 1 cell
10	0.1 nF	100 Ω	10 mH	120 V	Same as 1 cell

Key Takeaways for Builders

- Series wiring increases voltage, resistance, and inductance, but reduces total capacitance.
- Resonance frequency remains unchanged if you scale L and C proportionally.
- Gas output per cell is unchanged, but total system output depends on total current (which is the same as one cell).
- Ensure your power supply can handle the higher voltage required for more series cells.
- Safety first: Higher voltages mean greater insulation and shock protection are mandatory.

Copyright 2025 © Daniel Donatelli Secure Supplies Group All Rights Reserved

Here's a comprehensive builder's smart guide for Stanley Meyer WFC systems with **series-wired cells**.

This adapts your previous parallel-based scaling to the series case, showing exactly how capacitance, resistance, inductance, impedance, current, gas output, and voltage requirements change as you increase the number of series cells.

Stanley Meyer WFC Series Wiring: Electrical Scaling Guide

Fundamental Scaling Relationships (Series Wiring)

When cells are connected in series:

- Total Capacitance:

- Ctotal=Cunitn
- $C_{total}=nC_{unit}$*(Decreases as you add more cells)*
- Total Resistance:
- Rtotal=n×Runit
- $R_{total}=n\times R_{unit}$
- *(Increases as you add more cells)*
- Total Inductance:
- Ltotal=n×Lunit$L_{total}=n\times L_{unit}$
  (Increases as you add more cells)
- Current:Itotal=Iunit$I_{total}=I_{unit}$
- *(Same as a single cell)*
- Total Voltage Required:

- Vtotal=n×Vunit$V_{total}=n\times V_{unit}$
- *(Increases as you add more cells)*
- Gas Output:
  Gas Output Ratio=1

  Gas Output Ratio=1
  (Per series string, output is same as a single cell; to increase output, use multiple series strings in parallel)

Copyright 2025 © Daniel Donatelli Secure Supplies Group All Rights Reserved

Hydrogen Energy Development Fund
Operated & managed by Secure Supplies Investments limited
fueling healthy communities

Complete Scaling Parameters Table (Series Wiring, Relative to 10-Cell Base)

Cell Count	Capacitance Ratio	Resistance Ratio	Inductance Ratio	Impedance Ratio	Current Ratio	Gas Output Ratio	VIC Voltage Ratio	VIC Current Ratio
6	1.667	0.600	0.600	0.600	1.0	1.0	0.600	1.0
10	1.000	1.000	1.000	1.000	1.0	1.0	1.000	1.0
12	0.833	1.200	1.200	1.200	1.0	1.0	1.200	1.0
14	0.714	1.400	1.400	1.400	1.0	1.0	1.400	1.0
16	0.625	1.600	1.600	1.600	1.0	1.0	1.600	1.0
18	0.556	1.800	1.800	1.800	1.0	1.0	1.800	1.0
20	0.500	2.000	2.000	2.000	1.0	1.0	2.000	1.0
22	0.455	2.200	2.200	2.200	1.0	1.0	2.200	1.0
24	0.417	2.400	2.400	2.400	1.0	1.0	2.400	1.0

Copyright 2025 © Daniel Donatelli Secure Supplies Group All Rights Reserved

26	0.385	2.600	2.600	2.600	1.0	1.0	2.600	1.0
28	0.357	2.800	2.800	2.800	1.0	1.0	2.800	1.0
30	0.333	3.000	3.000	3.000	1.0	1.0	3.000	1.0
40	0.250	4.000	4.000	4.000	1.0	1.0	4.000	1.0
60	0.167	6.000	6.000	6.000	1.0	1.0	6.000	1.0
80	0.125	8.000	8.000	8.000	1.0	1.0	8.000	1.0
100	0.100	10.000	10.000	10.000	1.0	1.0	10.000	1.0
120	0.083	12.000	12.000	12.000	1.0	1.0	12.000	1.0
160	0.063	16.000	16.000	16.000	1.0	1.0	16.000	1.0
200	0.050	20.000	20.000	20.000	1.0	1.0	20.000	1.0
320	0.031	32.000	32.000	32.000	1.0	1.0	32.000	1.0

Copyright 2025 © Daniel Donatelli Secure Supplies Group All Rights Reserved

400	0.025	40.000	40.000	40.000	1.0	1.0	40.000	1.0
600	0.017	60.000	60.000	60.000	1.0	1.0	60.000	1.0
800	0.013	80.000	80.000	80.000	1.0	1.0	80.000	1.0
1200	0.008	120.000	120.000	120.000	1.0	1.0	120.000	1.0

All ratios are relative to a 10-cell series base configuration.

Visual Illustration

```text

Series Wiring Diagram:

+V  o--[Cell1]--[Cell2]--[Cell3]--...--[CellN]--o  -V

Current is the same through every cell.
Total voltage is the sum of all cell voltages.
```

Copyright 2025 © Daniel Donatelli Secure Supplies Group All Rights Reserved

Component Adjustment Requirements

Resonance Maintenance (Series)

- **Option A – Inductance Adjustment:**
  Increase external inductance by the inductance ratio factor.
  (e.g., for 20 cells, double the inductance; for 100 cells, increase by 10×.)
- **Option B – Capacitance Adjustment:**
  Decrease external capacitance by the capacitance ratio factor.
  (e.g., for 20 cells, halve the capacitance; for 100 cells, reduce to 1/10th.)
- **Option C** – V**IC Transformer Adjustment:**
  Increase VIC secondary turns ratio by the VIC voltage ratio.
  (e.g., for 20 cells, double the turns ratio; for 100 cells, increase by 10×.)

Copyright 2025 © Daniel Donatelli Secure Supplies Group All Rights Reserved

Critical Component Adjustments Table (Series)

Cell Count	External L Increase %	External C Decrease %	VIC Turns Change %	Current Draw Change %	Power Supply Voltage Increase %
12	20%	17%	20%	0%	20%
20	100%	50%	100%	0%	100%
30	200%	67%	200%	0%	200%
60	500%	83%	500%	0%	500%
100	900%	90%	900%	0%	900%
200	1900%	95%	1900%	0%	1900%
400	3900%	97.5%	3900%	0%	3900%
1200	11900%	99.2%	11900%	0%	11900%

Copyright 2025 © Daniel Donatelli Secure Supplies Group All Rights Reserved

Builder's Practical Guide (Series)

Complexity & Skill Level

- **Beginner (6–20 cells):**
  - Air cooling sufficient
  - Standard automotive power supply (but higher voltage needed)
  - Basic electrical skills required
  - Build time: 2–3 days
- **Intermediate (22–60 cells):**
  - Enhanced air cooling
  - Higher-voltage supply required (e.g., 72V–144V)
  - Advanced electrical knowledge
  - Build time: 3–4 days
- **Advanced (80–200 cells):**
  - Water cooling recommended
  - High-voltage, low-current supply (e.g., 240V–480V)
  - Professional expertise required
  - Build time: 4–6 days
- **Expert (320–1200 cells):**
  - Active water cooling
  - Industrial high-voltage supply (e.g., 1kV+)
  - Engineering-level expertise
  - Build time: 8–24 days

Power Supply Requirements (Series)

- Current:
  Stays the same as a single cell (does not increase with more cells in series).
- Voltage:
  Increases linearly with the number of cells.
  (e.g., 10 cells × 12V = 120V; 100 cells × 12V = 1200V)
- Safety Margin:
  Add 25% for startup surge.

Copyright 2025 © Daniel Donatelli Secure Supplies Group All Rights Reserved

Safety Considerations (Series)

- Standard Safety (6–20 cells):
  Basic electrical safety, fusing, grounding.
- Enhanced Safety (22–100 cells):
  Arc flash protection, current limiting, thermal monitoring.
- Industrial Safety (120–1200 cells):
  Professional protocols, interlocks, automated shutdown, proper enclosures.

Key Takeaways for Series-Wired Cells

- Voltage requirement increases with cell count—plan for insulation and safety.
- Current does NOT increase with more cells in series.
- Gas output per series string is the same as one cell.
  (To increase output, use multiple series strings in parallel.)
- Capacitance drops, resistance and inductance rise with more cells.
- Resonance frequency remains constant if L and C are scaled proportionally.
- High voltages require extra care for insulation, connectors, and safety systems.

Copyright 2025 © Daniel Donatelli Secure Supplies Group All Rights Reserved